JVC

# COLOUR TELEVISION

**EQUALIZER • CINEMA SURROUND • COMPONENT INPUT**

**AV-29LS24**
**AV-29LX14**
**AV-29VS24**
**AV-29VX54**
**AV-29VX74**
**AV-29WX14**
**AV-29WX24**
**AV-25LS24**
**AV-25LX14**
**AV-25VS24**
**AV-25VX54**
**AV-25VX74**
**AV-21CS24**
**AV-21CX14**
**AV-21DX14**
**AV-21LX14**
**AV-21VS24**
**AV-21VX14**
**AV-21VX54**
**AV-21VX74**
**AV-21WS24**
**AV-21WX14**
**AV-21YX14**

## Contents


Knowing your TV's features ..... 3
Remote control buttons and basic functions ..... 4
TV buttons and functions ..... 6
Setting up your TV ..... 7
Basic setting for picture ..... 9
Advanced setting for picture ..... 11
Original features for picture ..... 12
Basic setting for sound ..... 14
Advanced setting for sound ..... 15
Favorite channel and video setting ..... 16
Customized setting ..... 17
TV channel presetting ..... 19
Additional preparation ..... 22
Troubleshooting ..... 23
Specifications ..... Back cover


# *INSTRUCTIONS*

GGT0045-001C-H

Thank you for buying this JVC colour television.
To make sure you understand how to use your new TV, please read this manual thoroughly before you begin.

**WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.**
**CAUTION: TO ENSURE PERSONAL SAFETY, OBSERVE THE FOLLOWING RULES REGARDING THE USE OF THIS TV.**

1 Operate only from the power source indicated on the rear of the TV.
2 Avoid damaging the power cord and mains plug. When unplugging the TV, grasp the mains plug. Do not pull on the power cord.
3 Never block or cover the ventilation openings.
Never install the TV where good ventilation is unattainable.
When installing this TV, leave spaces for ventilation around the TV of more than the minimum distances as shown.




4 Do not allow objects or liquid into the cabinet openings.
5 In the event of a fault, unplug the unit and call a service technician. Do not attempt to repair it yourself or remove the rear cover.
6 The surface of the TV screen is easily damaged. Be very careful with it when handling the TV. Should the TV screen become soiled, wipe it with a soft dry cloth. Never rub it forcefully. Never use any cleaner or detergent on it.
7 If you are not going to use this TV for a long period of time, be sure to disconnect the AC plug from the AC socket.
8 The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

**WARNING: <AV-21WS24/AV-21WX14/AV-21YX14 only>**
**A REMOVABLE PLASTIC COVER IS FIXED TO THE TELEVISION'S FRONT AUDIO/VIDEO CONNECTOR. TO PREVENT THIS COVER FROM BEING ACCIDENTALLY SWALLOWED BY BABIES OR CHILDREN, REMOVE IT FROM THE TELEVISION AND STORE IT IN A SAFE PLACE. IF THE COVER IS SWALLOWED SEEK THE ADVICE OF A DOCTOR IMMEDIATELY.**

# Knowing your TV's features




## Main features

| | |
|---|---|
| **PIP (Picture in Picture)** | You can view two different sources (e.g. TV programme and VCR sources) at the same time. |
| **TELETEXT** | You can view teletext programmes which are broadcasted by some TV channels. Teletext programme is an information in text form. |
| **A2/NICAM (STEREO / I•II)** | You can listen to the stereo sound or bilingual sound from TV programme broadcasting by A2 or NICAM Sound-multiplex system. |
| **FAVORITE CH (Channel)** | You can register up to four favorite channels for quick recall with one press. |
| **AI ECO** | TV detects the brightness of your room and automatically adjust the picture brightness to a suitable level for a better eye care. |
| **AI VOLUME** | TV adjusts the volume automatically to the same level for all TV channels to avoid sudden change of the volume when selecting different TV channel. |

## Confirm your TV's functions

Some functions written in this instruction manual may not be available for your TV.
Please see the chart below and check the functions that are equipped for your TV's model number. The model number is indicated at the rear of your TV. When you press a button concerned to a function that is not available for your TV, it does not work and the logo "Ø" appears on the screen. For a function that is not available for your TV, it is not displayed in the menu.

| No. | Function \ Model No. | AV-29LX14 | AV-29WX14 | AV-25LX14 AV-21LX14 | AV-21VX14 AV-21WX14 | AV-29VX54 | AV-25VX54 AV-21VX54 | AV-29WX24 | AV-29LS24 | AV-29VS24 | AV-25LS24 | AV-21CS24 | AV-25VS24 AV-21WS24 AV-21VS24 | AV-29VX74 | AV-25VX74 AV-21VX74 | AV-21CX14 | AV-21DX14 | AV-21YX14 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| ❶ | I/II (STEREO/I•II) | – | – | – | – | – | – | – | ○ | ○ | ○ | ○ | ○ | – | – | – | – | – |
| ❷ | *PICTURE BOOSTER | – | – | – | – | – | – | – | – | – | – | – | – | – | – | – | – | ○ |
| ❸ | *ECO | – | ○ | – | ○ | ○ | ○ | ○ | – | ○ | – | – | ○ | ○ | ○ | – | – | – |
| ❹,❻ | PIP control buttons (Green label) | – | – | – | – | ○ | ○ | – | – | – | – | – | – | ○ | ○ | – | – | – |
| ❺,❻ | TELETEXT control buttons (Black label) | – | – | – | – | – | – | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | – | – | – |
| – | PICTURE TILT | ○ | ○ | – | – | ○ | – | ○ | ○ | ○ | – | – | – | ○ | – | – | – | – |
| – | COMPRESS (16:9) | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | – | ○ | ○ | ○ | – | ○ | – |

# Remote control buttons and basic functions

| No. | Press | To |
|---|---|---|
| ❶ | POWER | Turn on or off the TV from standby mode. |
| ❷ | MENU/OK | Display menu and confirm selected function. |
| ❸ | ▲ / ▼ / ◄ / ► | Select and adjust menu function. |
| ❹ | CHANNEL -/+ | Select the desired channel number. |
| ❺ | VOLUME -/+ | Adjust the volume level. |
| ❻ | TV/VIDEO | Select TV or video terminal input. |
| ❼ | MUTING | Turn off the volume.<br>Press this button again to resume the volume. |
| ❽ | DISPLAY | Display the programme number or video terminal number, stereo/bilingual broadcast system and PR list (channel list) on the screen.<br>You can select the channel using the PR list.<br>**1** Press the DISPLAY button once to display the PR list.<br>**2** Press ▲ / ▼ / ◄ / ► buttons to choose a channel, then press the MENU/OK button.<br>You can confirm the favorite channels in the PR list. The channels set to favorite channels are indicated with coloured mark. |
| ❾ | 0~9, -/-- | Select the programme number. For two digits programme number, press -/--, then press the number button. |
| ❿ | RETURN+ | a) Return to the frequently view channel with one touch.<br>**1** Choose the channel you want to register.<br>**2** Press and hold RETURN+ button until “RETURN PLUS PROGRAMMED!” appears.<br>To cancel, press and hold RETURN+ button until “RETURN PLUS CANCELED!” appears.<br>b) Return to the previously viewed channel, if you have not set or have cancelled the Return channel as above. |



## How to operate menus and menus locations

| To | Operation | Note |
|---|---|---|
| Display the MENU | Press the MENU/OK button ❷. | To exit the MENU, press the DISPLAY button ❽ or choose EXIT menu. |
| Display the top menu | Press ▲/▼ buttons ❸ to choose a menu title. Then press MENU/OK button ❷. | Press ▼ button ❸ to display the next page for more functions. |
| Display the 2nd menu | Press ▲/▼ buttons ❸ to choose a menu title. Then press MENU/OK button ❷. | |
| Display the 3rd menu | Press ▲/▼ buttons ❸ to choose a menu title. Then press MENU/OK button ❷. | |
| Return to the previous menu | Press the DISPLAY button ❽. | – |
| Choose the setting of a function | Press ▲/▼ buttons ❸ to choose a function. Then press the ◄/► buttons ❸ to change the setting. | Press the MENU/OK button ❷ to exit from the menu. |
| Adjust the effect level of a function | Press ▲/▼ buttons ❸ to choose a function. Then press the ◄/► buttons ❸ to adjust the effect level. | |
| Display the sub menu of a function. | Press the ▲/▼ buttons ❸ to choose a function. Then press MENU/OK button ❷ to display the sub menu. | – |

The following chart shows locations of functions in menus. In this manual, location of a function is described as follows:

(MENU) ➡ (Top menu) ➡ (2nd menu)

(MENU) ➡ (Top menu) ➡ (2nd menu) ➡ (3rd menu)

Note: Some functions have the 4th menus as the sub-menus.

| | Top menu | 2nd menu | Location | 3rd menu | Location |
|---|---|---|---|---|---|
| MENU | INPUT | EXT. INPUT | P.18 | – | – |
| | | DISPLAY | P.18 | – | – |
| | PICTURE<br>* If you want to adjust PICTURE SETTING menu, you must set PICTURE MODE menu to USER. | PICTURE MODE | P.9 | – | – |
| | | PICTURE SETTING | P.10 | – | – |
| | | WHITE BALANCE | P.10 | – | – |
| | | PICTURE FEATURES | – | VNR | P.17 |
| | | | | FAVORITE CH SETTING | P.16 |
| | | | | VIDEO SETTING | P.16 |
| | | | | COLOUR SYSTEM | P.9 |
| | | | | PICTURE BOOSTER | P.10 |
| | | | | COMPRESS (16:9) | P.11 |
| | | | | PICTURE TILT | P.11 |
| | SOUND<br>* If you want to adjust EQUALIZER menu, you must set SOUND MODE menu to USER. | STEREO/I•II | P.15 | – | – |
| | | AI VOLUME | P.15 | – | – |
| | | SOUND MODE | P.14 | – | – |
| | | EQUALIZER | P.15 | – | – |
| | | BALANCE | P.14 | – | – |
| | | SOUND TURBO | P.14 | – | – |
| | | CINEMA SURROUND | P.15 | – | – |
| | FEATURES | OFF TIMER | P.17 | – | – |
| | | CHILD LOCK | P.17 | – | – |
| | | AI ECO SENSOR | P.11 | – | – |
| | | PIP | – | PIP,SUB INPUT,SWAP | P.12 |
| | INSTALL | AUTO PROGRAM | P.19 | – | – |
| | | EDIT/MANUAL | P.19 | DELETE, MOVE, MANUAL, INSERT | P.19-P.20 |
| | | LANGUAGE | P.17 | LANGUAGE | P.17 |
| | | BLUE BACK | P.11 | – | – |
| | | AUTO SHUTOFF | P.18 | – | – |
| | | VIDEO-2 SETTING | P.18 | – | – |
| | | AI ECO DISPLAY | P.11 | – | – |
| | | TEXT LANGUAGE | P.13 | TEXT LANGUAGE | P.13 |
| | EXIT | – | – | – | – |

# TV buttons and functions

The illustrations shown below is for AV-29VS24 and AV-21CS24 only, which are used for explanation purpose.
Your TV may not look exactly the same as illustrated.

### Front of the TV

AV-29VS24




AV-21CS24




### Rear of the TV

AV-29VS24




AV-21CS24




| No. | Button/terminal | Description | Page |
|---|---|---|---|
| ❶ | ⏻ (main power) | Press to turn on or turn off the TV's main power. | – |
| ❷ | POWER lamp | Indicate the TV is being turned on or off.<br>No colour : TV's main power is being turned off.<br>Red : TV's main power is being turned on.<br>Note: When you turn off the power switch while TV is in standby mode, the light of power lamp will be off in 10 -15 seconds. | – |
| ❸ | ECO sensor | | – |
| ❹ | Remote control sensor | | – |
| ❺ | TV/VIDEO | Press to select TV or video mode. | – |
| ❻ | VOLUME -/+ | Press to adjust the volume level. | – |
| ❼ | CHANNEL -/+ | Press to select the desired channel. | – |
| ❽ | MENU | Press to display the menu. | – |
| ❾ | IN (VIDEO-3) | Video and audio input jacks for VIDEO-3 mode. | 22 |
| | IN (VIDEO-2) | Video and audio input jacks for VIDEO-2 mode. | 22 |
| ❿ | 🎧 | Headphone jack. | 22 |
| ⓫ | ⊤ | Aerial socket. | 7 |
| ⓬ | OUTPUT | Video and audio output jacks. (The component video signal cannot be output.) | 22 |
| ⓭ | COMPONENT (VIDEO-2) INPUT | Video or component video, and audio input jacks for VIDEO-2 mode. You can select the input signal by setting the "VIDEO-2 SETTING" function (see page 18). | 22 |
| ⓮ | VIDEO-1 INPUT | Video or S-VIDEO, and audio input jacks for VIDEO-1 mode | 7 |

**How to operate the menus with the TV button**

| TV button | Work as same as the button on the remote control unit | Note |
|---|---|---|
| MENU | MENU/OK button | To display main menu and exit menu after finish setting. |
| CHANNEL -/+ | ▼/▲ button | To select menu function. |
| VOLUME -/+ | ◄/► button | To adjust the desired function. |

# Setting up your TV

**CAUTION**

- Turn off the equipment including the TV before connecting.

**1 Connecting the aerial cable.**




If you connect a VCR, connect the aerial output jack of your VCR and the aerial jack on the TV with aerial cable. Then connect the output jacks of your VCR and the VIDEO-1 input jacks of the TV with the video cable (or S-VIDEO cable if available) and audio cables. For details, see the manual of your VCR.




The illustration shown is just a sample. It may not be same as your TV.

**2 Connecting the compatible main plug to the AC outlet.**



**3 Inserting batteries into the remote control.**

Insert two batteries by following the ⊕ and ⊖ polarities and inserting the ⊖ end first.

**CAUTION:**

Follow the cautions printed on the batteries.

Notes:

- Use AA/R6/UM-3 dry cell batteries.
- If the remote control does not work properly, fit new batteries. The supplied batteries are for testing, not regular use.



**4 Turn on the TV by pressing the main power button.**

JVC logo appears on the screen.

**5 Making the initial settings**

Set up your TV by pressing any button except POWER button, then operate the TV menu by following the steps as below:




- Press ▲/▼ button to select your desired language*, then press MENU/OK button.




- Press ▲/▼ button to select your desired Teletext language group*. For details, see page 13. (For CS24/LS24/ VS24/VX74/WS24/ WX24 series only)




- TV will start searching for the channels.

  To stop AUTO PROGRAM, press MENU/OK button.




- Press the red button to cancel the SETUP TOUR RESTART function.
  If you want to make initial settings again when the next time you turn on the TV, press the MENU/OK button to activate the SETUP TOUR RESTART function.




- To complete the initial setting, press the MENU/OK button. To edit the channel list, see page 19.

If the JVC logo does not appear, use LANGUAGE, TEXT LANGUAGE, and AUTO PROGRAM functions to make the initial settings. Those functions are located in the INSTALL menu.

If the JVC logo appears, although you had made the initial settings, press the TV/VIDEO button to exit from initial settings.

* If the TEXT function is available for your TV and the LANGUAGE shown follow as ENGLISH/РУССКИЙ/ عربي / فارسغ ی /FRANÇAIS, you can select the TEXT LANGUAGE group from GROUP-1 to GROUP-4.
If the TEXT function is available for your TV and the LANGUAGE shown follow as ENGLISH/РУССКИЙ/ 中 文/MELAYU/INDONESIA, you can select the TEXT LANGUAGE group from GROUP-1 to GROUP-3.

# Basic setting for picture

## COLOUR SYSTEM

You can select the appropriate colour system when the picture is not clear or no colour appears.
Press the COLOUR SYSTEM button to select a setting.




To operate this function with a menu:

✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (COLOUR SYSTEM)

For the colour system in each country or region, see the table below:

| Area | Country or Region | System |
|---|---|---|
| Asia, Middle East | Bahrain, Kuwait, Oman, Qatar, United Arab Emirates, Yemen, etc.<br>Indonesia, Malaysia, Singapore, Thailand, India, etc. | PAL |
| | China, Vietnam, etc. | PAL |
| | Hong Kong, etc. | PAL |
| | Islamic Republic of Iran, Lebanon, Saudi Arabia, etc. | SECAM |
| | Philippines, Taiwan, Myanmar, etc. | NTSC |
| Europe | Russia, etc. | SECAM |
| | Czech Republic, Poland, etc. | PAL |
| | Germany, Holland, Belgium, etc. | PAL |
| | UK, etc. | PAL |
| Oceania | Australia, New Zealand, etc. | PAL |
| Africa | Republic of South Africa, etc. | PAL |
| | Nigeria, etc. | PAL |
| | Egypt, Morocco, etc. | SECAM |

## PICTURE MODE

You can choose the desired picture setting with one-touch.
Press the PICTURE MODE button to select a setting.

| | |
|---|---|
| SOFT | Softens contrast and sharpness. |
| BRIGHT | Heightens contrast and sharpness. |
| STANDARD | Standard picture setting. |
| USER | You can change this picture setting as you like. Select USER and adjust following items in the PICTURE SETTING menu. (CONTRAST, BRIGHT, SHARP, COLOUR, TINT*) |

*TINT can only be adjusted in NTSC system.

To operate this function with a menu:

✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE MODE)

To return the USER setting to the default, press the blue button when the PICTURE SETTING menu appears.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

## Adjusting the picture – USER

You can adjust the desired picture setting when selecting USER in PICTURE MODE.

**1** Select the USER in PICTURE MODE under PICTURE menu.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE MODE) ➔ (USER)

**2** Select the PICTURE SETTING in PICTURE menu, then adjust the setting.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE SETTING)

| | | |
|---|---|---|
| CONTRAST | ◄ : Lower contrast | ► : Higher contrast |
| BRIGHT | ◄ : Darker | ► : Brighter |
| SHARP | ◄ : Softer | ► : Higher |
| COLOUR | ◄ : Lighter | ► : Deeper |
| TINT* | ◄ : Reddish | ► : Greenish |

*TINT can only be adjusted in NTSC system.

## PICTURE BOOSTER

You can improve picture clarity when the picture is unclear due to the low signal reception.
Press the PICTURE BOOSTER button to select the desired mode.

| | |
|---|---|
| HIGH | Perform at maximum level. |
| LOW | Perform at minimum level. |
| OFF | Cancel the function |

To operate this function with a menu:
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (PICTURE BOOSTER)

## WHITE BALANCE

You can change the white balance of the picture to better match the type of video being viewed.
Select the WHITE BALANCE in the PICTURE menu, then choose the desired setting.
✳ (MENU) ➔ (PICTURE menu) ➔ (WHITE BALANCE)

| | |
|---|---|
| NORMAL | Normal white balance. |
| COOL | Bluish white. |
| WARM | Reddish white. |

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

# Advanced setting for picture

## AI ECO SENSOR (ECO)

You can adjust TV screen contrast according to the brightness of your room.
Press the ECO button to select the desired mode.

| | |
|---|---|
| 1 | Mild contrast (recommended). |
| 2 | Even contrast. |
| OFF | Cancel the function. |

To operate this function with a menu:
✳ (MENU) ➔ (FEATURES menu) ➔ (AI ECO SENSOR)

You can display the graphic of AI ECO SENSOR on the screen. Select the AI ECO DISPLAY in the INSTALL menu, then choose ON or OFF.
✳ (MENU) ➔ (INSTALL menu) ➔ (AI ECO DISPLAY)

## Correcting the Slanting Picture (PICTURE TILT)

You can correct the picture tilt caused by the earth's magnetic force.

**1** Select the PICTURE TILT in the PICTURE FEATURES menu under PICTURE menu, then press MENU/OK button.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (PICTURE TILT)
The following display appears.




**2** Press the ▲/▼ buttons until the picture become level. Then press the MENU/OK button.

## COMPRESS (16:9)

You can convert a normal picture (4:3 aspect ratio) into a wide picture (16:9 aspect ratio).
Select the COMPRESS (16:9) in the PICTURE FEATURES menu under PICTURE menu, then choose ON or OFF.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (COMPRESS (16:9))

## BLUE BACK

You can set the TV to automatically change to a blue screen and mute the sound if the signal is weak or absent, or when there is no input from an antenna.

Select the BLUE BACK in the INSTALL menu, then choose ON or OFF.
✳ (MENU) ➔ (INSTALL menu) ➔ (BLUE BACK)

If you wish to continue viewing the poor picture, cancel the BLUE BACK function.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

# Original features for picture

## PIP

You can display a sub picture on the screen.
Press the PIP operation buttons to display and change the sub picture setting.

| | |
|---|---|
| PIP | Display the sub picture.<br>To cancel, press the PIP button again.<br>**Notes:**<br>• You can hear the sound from the main picture only.<br>• Main picture and sub picture will use different input sources, which are TV and VIDEO mode.<br>When the same input source are selected, the sub picture input source will change as follows:<br>Main picture / Sub picture<br>TV / VIDEO-1 → VIDEO-2 → VIDEO-3<br>VIDEO-1 / TV → VIDEO-2 → VIDEO-3<br>VIDEO-2 / TV → VIDEO-1 → VIDEO-3<br>VIDEO-3 / TV → VIDEO-1 → VIDEO-2 |
| SUB-P -/+ | Select the desired channel for sub picture. |
| (Input) | Select the input source for the sub picture. |
| (Swap) | Swap between the main picture and sub picture. |
| (Position) | Change the sub picture position.<br>Each time you press on (Position) button, the sub picture position will change as follows:<br>lower right → lower left → upper left → upper right → lower right |
| (Freeze) | Freeze the sub picture to be still. |

To operate this function with a menu:

✳ (MENU) ➔ (FEATURES menu) ➔ (PIP)

When VIDEO-2 is set to component, you can't select VIDEO-2 for sub picture.

When VIDEO-2 is set to component, if the input source of main picture is set to VIDEO-2 with component, PIP button is disabled and sub picture can't be displayed.

## TELETEXT

You can watch the Teletext broadcast channel with TEXT function.

**1** Press the TEXT button to select the desired mode as follows:

TV mode → TEXT mode → MIX mode

**2** Press the CHANNEL -/+ buttons, number buttons or colour buttons to select other Teletext pages.

**3** Press TEXT or TV/VIDEO button to return to TV mode.

You can also operate the teletext using the following buttons:

| | |
|---|---|
| (Hold) | Hold a teletext page.<br>The (Hold) are displayed at the top left of the screen.<br>To cancel, press (Hold) button again. |
| (Reveal) | Display the hidden text (e.g. answers to a quiz).<br>To cancel, press (Reveal) button again. |
| (Size) | Enlarge the teletext display. |
| (Index) | Return to the index page instantly. |
| (Cancel) | Watch TV programme while waiting for a teletext page.<br>When the teletext page is found, a page number appears at the upper left of the screen.<br>Press (Cancel) to view the teletext page. |
| (Sub-page) | Operate the (Sub-page) function.<br>Sub-page numbers are displayed at the left of the screen.<br>To cancel sub-page function, press (Sub-page) button again. |

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

**Using the List mode**

You can store and recall the favorite teletext pages in memory using the colour buttons.

**1** In TEXT mode, press the MODE button to enter the List mode.

**2** Press a colour button, then press the number buttons to enter the page number.

**3** Press and hold down the ◇ (Store) button.
The page number is blinking white to indicate that they are stored in memory.

**4** To store other favorite teletext pages, repeat Step 2 to 3.

To recall the favorite teletext page, press the MODE button, then press the colour button.
To exit the List mode, press the MODE button again.
When viewing teletext programme, menu operations are not available.
If characters on a teletext programme do not appear properly, change the TEXT LANGUAGE setting.

## TEXT LANGUAGE

You can set the Teletext language group that corresponds to the programmes.
Select TEXT LANGUAGE in the INSTALL menu, then choose the desired language group.

✳ (MENU) ➔ (INSTALL menu) ➔ (TEXT LANGUAGE)

| | |
|---|---|
| GROUP-1 | English, German, Swedish / Finnish / Danish / Hungarian, Italian, French, Spanish / Portuguese, Turkish |
| GROUP-2 | Polish, German, Estonian, Slovenian, Czech / Slovakian, Rumanian |
| GROUP-3 | Polish, German, Estonian, Lettish, Russian, Ukrainian |
| GROUP-4 | English, French, Turkish, Arabic, Iranian |

Depending on the broadcast, the language set may not display properly. For details, see in page 8.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

# Basic setting for sound

## SOUND SYSTEM

You can select an appropriate sound system when abnormal sound occurs even when the picture appears normally.
Press the SOUND SYSTEM button to select a setting.

→ B/G → I → D/K → M →

This function is not available in video mode.
For the sound system in each country or region, see the table below:

| Area | Country or Region | System |
|---|---|---|
| Asia, Middle East | Bahrain, Kuwait, Oman, Qatar, United Arab Emirates, Yemen, etc.<br>Indonesia, Malaysia, Singapore, Thailand, India, etc. | B/G |
| | China, Vietnam, etc. | D/K |
| | Hong Kong, etc. | I |
| | Islamic Republic of Iran, Lebanon, Saudi Arabia, etc. | B/G |
| | Philippines, Taiwan, Myanmar, etc. | M |
| Europe | Russia, etc. | D/K |
| | Czech Republic, Poland, etc. | D/K |
| | Germany, Holland, Belgium, etc. | B/G |
| | UK, etc. | I |
| Oceania | Australia, New Zealand, etc. | B/G |
| Africa | Republic of South Africa, etc. | I |
| | Nigeria, etc. | B/G |
| | Egypt, Morocco, etc. | B/G |

## SOUND MODE

You can choose the desired sound setting.
Select the SOUND MODE in SOUND menu, then choose the setting.

✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE)

| | |
|---|---|
| USER | You can change this sound setting as you like.<br>Select USER and adjust the frequencies in EQUALIZER (100, 300, 1K, 3K, 8K Hz).<br>For details, see “EQUALIZER” on page 15. |
| DYNAMIC | Emphasize on both vocal sound and music. |
| MUSIC | Emphasize on music effect. |
| NEWS | Emphasize on vocal sound. |

## BALANCE

You can adjust the volume balance between the left and right speakers.
Select the BALANCE in SOUND menu, then adjust the setting.

✳ (MENU) ➔ (SOUND menu) ➔ (BALANCE)

## SOUND TURBO

You can set the sound frequency to emphasize the low and high frequency levels.

Press the SOUND TURBO to select ON or OFF.
To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (SOUND TURBO)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

# Advanced setting for sound

## CINEMA SURROUND

You can enjoy an enhanced sound for wider audience.
Press the CINEMA SURROUND button to select a setting.

| | |
|---|---|
| OFF | Cancel the function. |
| LOW | Listen to sound with less wider audience effect. |
| HIGH | Listen to sound with more wider audience effect. |
| MONO | Listen to mono sound with stereo effect. |

To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (CINEMA SURROUND)

If slight volume distortion occurs when you select HIGH mode, change the setting to LOW mode. The CINEMA SURROUND effect will be less noticeable.
If you use CINEMA SURROUND and SOUND TURBO together, volume distortion might occurs.

## STEREO / I-II ( I/II )

You can enjoy the stereo and bilingual broadcasted programmes.
Press the I/II button to select the desired mode.

| | |
|---|---|
| | Select stereo sound. |
| | Select monaural sound. |
| I | Select bilingual I (sub I). |
| II | Select bilingual II (sub II). |
| MONO | Cancels the Multi Sound function, and the sound becomes monaural. |

This function is not available in video mode.
To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (STEREO / I-II)

## EQUALIZER

You can adjust the sound frequencies when selecting USER mode in SOUND MODE.

**1** Select the USER in SOUND MODE under SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE) ➔ (USER)

**2** Select the EQUALIZER in SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (EQUALIZER)

The following display appears.




**3** Select and adjust the desired frequencies.

**4** Press the MENU/OK button to exit the menu.

Adjust high frequency will affect higher pitch sound and vice versa.

## AI VOLUME

You can adjust the volume of all the channels and video inputs to the same level automatically.
Select the AI VOLUME in SOUND menu, then choose ON or OFF.

✳ (MENU) ➔ (SOUND menu) ➔ (AI VOLUME)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

# Favorite channel and video setting

## To register the favorite channel

You can register and recall 4 favorite channels by using the colour buttons (red, green, yellow, blue).

**1** In TV mode, select a TV channel (PR01-99) you desired to register.

**2** Press and hold a colour button for 3 seconds or more.
"FAVORITE CHANNEL ■ PROGRAMMED" appears on the screen and current channel is registered.

**3** To register other favorite channels, repeat Step 1 to 2.

To recall the favorite channel, press the colour button.
When the TV is in Text mode, Picture in Picture or menu mode, favorite channel function is not available.

## To adjust favorite channel setting (FAVORITE CH SETTING)

You can adjust the picture and sound settings for the favorite channels.

**1** Display the PICTURE menu and select FAVORITE CH SETTING in PICTURE FEATURES menu.
✳(MENU) ➡ (PICTURE menu) ➡ (PICTURE FEATURES menu) ➡ (FAVORITE CH SETTING)

**2** Select FAVORITE CHANNEL in FAVORITE CH SETTING menu, then choose the desired favorite channel.
✳(FAVORITE CH SETTING) ➡ (FAVORITE CHANNEL)

**3** Select EFFECT, then press ◄/► button to choose ON.
To cancel the settings, choose OFF.




**4** Select the desired item that you wish to adjust.
CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR ↔ SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT

**5** Press the MENU/OK button to exit the menu.

## To adjust the video setting (VIDEO SETTING)

You can adjust the picture and sound settings for video inputs.

**1** Display the PICTURE menu and select VIDEO SETTING in PICTURE FEATURES menu.
✳(MENU) ➡ (PICTURE menu) ➡ (PICTURE FEATURES menu) ➡ (VIDEO SETTING)

**2** Select VIDEO STATUS in VIDEO SETTING menu, then choose the desired video input.
✳(VIDEO SETTING) ➡ (VIDEO STATUS)

**3** Select EFFECT, then press ◄/► button to choose ON.
To cancel the settings, choose OFF.




**4** Select the desired item that you wish to adjust.
CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR ↔ SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT

**5** Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

# Customized setting

## VNR

You can reduce the noise.
Select the VNR in the PICTURE FEATURES menu under PICTURE menu, then choose a setting of VNR function.

✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (VNR)

| | |
|---|---|
| OFF | VNR is turned off. |
| AUTO | Effect of VNR is automatically controlled. |
| MIN | Effect of VNR becomes minimum level. |
| MAX | Effect of VNR becomes maximum level. |

If you select MAX, the picture becomes softer even if the original picture is sharp.

## LANGUAGE

You can choose your desired on screen display language.
Select the LANGUAGE in the INSTALL menu, then choose a language.

✳ (MENU) ➔ (INSTALL menu) ➔ (LANGUAGE)

## CHILD LOCK

You can disable the front control buttons of the TV.
Select the CHILD LOCK in the FEATURES menu, then choose ON or OFF.

✳ (MENU) ➔ (FEATURES menu) ➔ (CHILD LOCK)

## OFF TIMER

You can set the TV to turn off automatically to standby mode after a set time.
Press the OFF TIMER button to select a desired period of time.




You can set the period of time to a maximum of 120 minutes in 10 minutes step.

To operate this function with a menu:

✳ (MENU) ➔ (FEATURES menu) ➔ (OFF TIMER)

When the elapsed of time left one minute, “GOOD NIGHT!” appears on the screen.
You can display the OFF TIMER menu again to confirm or change the remaining time.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

## AUTO SHUTOFF

You can set the TV to turn off automatically when no signal is received for about 15 minutes or longer after the end of a broadcast.
Select AUTO SHUTOFF in INSTALL menu, then choose ON or OFF.

✳ (MENU) ➡ (INSTALL menu) ➡ (AUTO SHUTOFF)

The AUTO SHUTOFF function does not turn off the TV's main power.
The AUTO SHUTOFF function is not available in video mode.

## VIDEO-2 SETTING

You can set the VIDEO-2 SETTING according to the video signal output from the external devices connected to the VIDEO-2 terminal.
Select the VIDEO-2 SETTING in INSTALL menu, then choose a setting.

✳ (MENU) ➡ (INSTALL menu) ➡ (VIDEO-2 SETTING)

| | |
|---|---|
| VIDEO | If a normal video signal (composite video signal) is input. |
| COMPONENT | If a component video signal ($Y/C_B/C_R$) is input. |

For connecting methods, see "Additional Preparation" on page 22.

## EXT. INPUT (TV/VIDEO)

You can select TV or video terminal input with one touch.
Press the TV/VIDEO button to select an input.
To operate this function with a menu:

✳ (MENU) ➡ (INPUT menu) ➡ (EXT. INPUT)

## DISPLAY

You can display the programme number, video terminal number and PR list on the screen.
Press the DISPLAY button to select the desired mode:

ON → OFF → PR LIST

Choose a TV channel or a VIDEO terminal.

**1** Press the DISPLAY button to display the PR LIST.

**2** Select a programme number or video terminal by pressing the ▲/▼ button to move up/down on the programme number or press the ◄/► button to skip for each 7 programme numbers, then press MENU/OK button.




To operate this function with a menu:

✳ (MENU) ➡ (INPUT menu) ➡ (DISPLAY)

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

# TV channel presetting

## To register the TV channels automatically

You can register the TV channels into the TV's channel list automatically.

**1** Display the INSTALL menu.
✳ (MENU) ➔ (INSTALL menu)

**2** Choose AUTO PROGRAM, then press the MENU/OK button.
AUTO PROGRAM function starts, and the channels received are registered in the channel list (PR LIST) automatically.

**3** "SETUP TOUR RESTART?" appears.

| | |
|---|---|
| To start the SETUP TOUR | Press the MENU/OK button. Then proceed to step 5 of "Setting up your TV" on page 8. |
| To skip the SETUP TOUR | Press the Red button. |

**4** The EDIT menu appears.

| | |
|---|---|
| To edit the channel list | Proceed to the Step 3 of "To edit the channel list (PR LIST)" on page 20. |
| If a channel is not registered | Proceed to the Step 3 of "To register the TV channels manually" on this page. |
| To exit the menu | Press the MENU/OK button. |

For details of "SETUP TOUR", see page 8.

## To register the TV channels manually (MANUAL in the EDIT menu)

You can register the TV channels into the TV's channel list manually.

**1** Display the INSTALL menu.
✳ (MENU) ➔ (INSTALL menu)

**2** Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.




**3** Choose the channel which you want to register.

**4** Press the blue button to activate the MANUAL function.
The sound system of the channel appears at the right of the CH/CC number.

**5** Press the ► button to choose an appropriate sound system.
For details, see "SOUND SYSTEM" on page 14.

**6** Press the green or red button to search for the TV channel.
Searching stops when a channel is found and displayed.

**7** Repeat step 5 until your desired TV channel appears.

| | |
|---|---|
| If the reception is poor | Press the blue or yellow button to fine tune the TV channel. |
| If noisy sound is heard | Press the ► button to choose an appropriate sound system. |

**8** Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

## To edit the channel list (PR LIST) (MOVE and DELETE in the EDIT menu)

You can edit the TV channel list as you like.
Note: After this operation, other channel's PR numbers will be changed.

**1** Display the INSTALL menu.
✳ (MENU) ➔ (INSTALL menu)

**2** Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.




**3** Choose the channel which you want to change PR number, or delete.

**4** Do the following action:

| | |
|---|---|
| To change the PR number (MOVE) | Press the ► button. Then move it to the PR number you want to use it for the channel. Finally press the ◄ button. |
| To delete the channel (DELETE) | Press the yellow button. |

**5** Press the MENU/OK button to exit the menu.

## To add in the new channel (INSERT in the EDIT menu)

You can add in the new channel in the TV channel list as you like. You need to find the "CH/CC" number for the TV channel. Find the "CH/CC" number corresponding to the channel number of the TV channel from the attached sheet "CH/CC number list" on page 21.

**1** Display the INSTALL menu.
✳ (MENU) ➔ (INSTALL menu)

**2** Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.

**3** Choose the PR number for which you will register a new TV channel. When you add a new TV channel of NTSC-M system, press the SOUND SYSTEM button to change the sound system to M. Then proceed to the next step.

**4** Press the green button, then press ▲/▼ buttons to choose "CC" or "CH".

**5** Press the number button to enter the remaining CH/CC number.
The TV starts to search the TV channel, and the picture of the TV channel appears. If the TV finds no TV channel, a noisy picture appears.

When a TV channel has already been registered in PR99, using the INSERT function deletes that TV channel.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

## CH/CC number

When you want to use the INSERT function on page 20, find the CH/CC number corresponding to the channel number of the TV channel from this table.

| Channel No. | Country |
|---|---|
| US | United States, Philippines, etc.. |
| CCIR | Middle East, Southeast Asia, etc.. |
| OIRT | Eastern Europe, Russia, Vietnam, etc.. |
| AUSTRALIA | Australia, etc.. |

### Channel

| CH | US | CCIR | OIRT | AUSTRALIA |
|---|---|---|---|---|
| CH 02 | US-2 | E2 | R1 | AU-0 |
| CH 03 | US-3 | E3 | | AU-1 |
| CH 04 | US-4 | E4 | R2 | AU-2 |
| CH 05 | US-5 | E5 | R6 | AU-6 |
| CH 06 | US-6 | E6 | R7 | AU-7 |
| CH 07 | US-7 | E7 | R8 | AU-8 |
| CH 08 | US-8 | E8 | R9 | AU-9 |
| CH 09 | US-9 | E9 | | |
| CH 10 | US-10 | E10 | R10 | AU-10 |
| CH 11 | US-11 | E11 | R11 | AU-11 |
| CH 12 | US-12 | E12 | R12 | |
| CH 13 | US-13 | | | |
| CH 14 | US-14, W+29 | | | |
| CH 15 | US-15, W+30 | | | |
| CH 16 | US-16, W+31 | | | |
| CH 17 | US-17, W+32 | | | |
| CH 18 | US-18, W+33 | | | |
| CH 19 | US-19, W+34 | | | |
| CH 20 | US-20, W+35 | | | |
| CH 21 | US-21, W+36 | E21 | | |
| CH 22 | US-22, W+37 | E22 | | |
| CH 23 | US-23, W+38 | E23 | | |
| CH 24 | US-24, W+39 | E24 | | |
| CH 25 | US-25, W+40 | E25 | | |
| CH 26 | US-26, W+41 | E26 | | |
| CH 27 | US-27, W+42 | E27 | | |
| CH 28 | US-28, W+43 | E28 | | |
| CH 29 | US-29, W+44 | E29 | | |
| CH 30 | US-30, W+45 | E30 | | |
| CH 31 | US-31, W+46 | E31 | | |
| CH 32 | US-32, W+47 | E32 | | |
| CH 33 | US-33, W+48 | E33 | | |
| CH 34 | US-34, W+49 | E34 | | |
| CH 35 | US-35, W+50 | E35 | | |
| CH 36 | US-36, W+51 | E36 | | |
| CH 37 | US-37, W+52 | E37 | | |
| CH 38 | US-38, W+53 | E38 | | |
| CH 39 | US-39, W+54 | E39 | | |
| CH 40 | US-40, W+55 | E40 | | |
| CH 41 | US-41, W+56 | E41 | | |
| CH 42 | US-42, W+57 | E42 | | |
| CH 43 | US-43, W+58 | E43 | | |
| CH 44 | US-44, W+59 | E44 | | |
| CH 45 | US-45, W+60 | E45 | | |
| CH 46 | US-46, W+61 | E46 | | |
| CH 47 | US-47, W+62 | E47 | | |
| CH 48 | US-48, W+63 | E48 | | |
| CH 49 | US-49, W+64 | E49 | | |
| CH 50 | US-50, W+65 | E50 | | |
| CH 51 | US-51, W+66 | E51 | | |
| CH 52 | US-52, W+67 | E52 | | |
| CH 53 | US-53, W+68 | E53 | | |
| CH 54 | US-54, W+69 | E54 | | |
| CH 55 | US-55, W+70 | E55 | | |
| CH 56 | US-56, W+71 | E56 | | |
| CH 57 | US-57, W+72 | E57 | | |
| CH 58 | US-58, W+73 | E58 | | |
| CH 59 | US-59, W+74 | E59 | | |
| CH 60 | US-60, W+75 | E60 | | |
| CH 61 | US-61, W+76 | E61 | | |
| CH 62 | US-62, W+77 | E62 | | |
| CH 63 | US-63, W+78 | E63 | | |
| CH 64 | US-64, W+79 | E64 | | |
| CH 65 | US-65, W+80 | E65 | | |
| CH 66 | US-66, W+81 | E66 | | |
| CH 67 | US-67, W+82 | E67 | | |
| CH 68 | US-68, W+83 | E68 | | |
| CH 69 | US-69, W+84 | E69 | | |

| CC | US | CCIR | OIRT | AUSTRALIA |
|---|---|---|---|---|
| CC 01 | | S-1 | | AU-5 |
| CC 02 | | S-2 | | |
| CC 03 | | S-3 | | |
| CC 04 | | S-4 | | |
| CC 05 | | S-5 | | |
| CC 06 | | S-6 | | AU-5A |
| CC 07 | | S-7 | | |
| CC 08 | | S-8 | | |
| CC 09 | | S-9 | | |
| CC 10 | | S-10 | | |
| CC 11 | | S-11 | | |
| CC 12 | | S-12 | | |
| CC 13 | | S-13 | | |
| CC 14 | A | S-14 | | |
| CC 15 | B | S-15 | | |
| CC 16 | C | S-16 | | |
| CC 17 | D | S-17 | | |
| CC 18 | E | S-18 | | |
| CC 19 | F | S-19 | | |
| CC 20 | G | S-20 | | |
| CC 21 | H | S-21 | | |
| CC 22 | I | S-22 | | |
| CC 23 | J | S-23 | | |
| CC 24 | K | S-24 | | |
| CC 25 | L | S-25 | | |
| CC 26 | M | S-26 | | |
| CC 27 | N | S-27 | | |
| CC 28 | O | S-28 | | |
| CC 29 | P | S-29 | | |
| CC 30 | Q | S-30 | | |
| CC 31 | R | S-31 | | |
| CC 32 | S | S-32 | | |
| CC 33 | T | S-33 | | |
| CC 34 | U | S-34 | | |
| CC 35 | V | S-35 | | |
| CC 36 | W | S-36 | | |
| CC 37 | W+1 | S-37 | | |
| CC 38 | W+2 | S-38 | | |
| CC 39 | W+3 | S-39 | | |
| CC 40 | W+4 | S-40 | | |
| CC 41 | W+5 | S-41 | | |
| CC 42 | W+6 | | | |
| CC 43 | W+7 | | | |
| CC 44 | W+8 | | | |
| CC 45 | W+9 | | | |
| CC 46 | W+10 | | | |
| CC 47 | W+11 | | | |
| CC 48 | W+12 | | | |
| CC 49 | W+13 | | | |
| CC 50 | W+14 | | | |
| CC 51 | W+15 | | | |
| CC 52 | W+16 | | | |
| CC 53 | W+17 | | | |
| CC 54 | W+18 | | | |
| CC 55 | W+19 | | | |
| CC 56 | W+20 | | | |
| CC 57 | W+21 | | | |
| CC 58 | W+22 | | | |
| CC 59 | W+23 | | | |
| CC 60 | W+24 | | | |
| CC 61 | W+25 | | | |
| CC 62 | W+26 | | | |
| CC 63 | W+27 | | | |
| CC 64 | W+28 | | | |
| CC 75 | | X | | |
| CC 76 | | Y | R3 | |
| CC 77 | | Z | R4 | AU-3 |
| CC 78 | | Z+1 | R5 | |
| CC 79 | | Z+2 | | AU-4 |
| CC 95 | A-5 | | | |
| CC 96 | A-4 | | | |
| CC 97 | A-3 | | | |
| CC 98 | A-2 | | | |
| CC 99 | A-1 | | | |

# Additional preparation

The illustrations shown in this section are for AV-29VS24 and AV-21CS24 only, which are used for explanation purpose. Your TV may not look exactly the same as illustrated.

**Before connecting**

- Read the manuals provided with the devices for the proper connection.
- Turn off all the devices including the TV.
- Note that connecting cables are not supplied.

## Connecting to front video input terminal




## Connecting to rear component/video input terminal and output terminal







When you use VIDEO-1 INPUT, you should choose to connect S-VIDEO or video input. If S-VIDEO connector and video input are connected at the same time, no picture displays on the screen and the message “PLEASE DISCONNECT VIDEO-1 CABLE!” appears. In this case, you should disconnect either S-VIDEO or video input.

When connecting to COMPONENT (VIDEO-2) input, depending on the connection, choose the appropriate video input using the menu (see page 18).

# Troubleshooting

If a problem occurs when you are using the TV, check the below troubleshooting guide before calling for repair.

| | |
|---|---|
| • No picture, no sound | • Deactivate the BLUE BACK function if it is turned on.<br>• Choose the appropriate sound system. Refer to “SOUND SYSTEM” on page 14. |
| • Snowy picture | • Check the aerial cable and its connection with the TV. |
| • Stripes appear on the picture | • Interference occurs caused by other devices such as an amplifier, personal computer, or a hair drier. Move such devices away from your TV. |
| • Double-pictures (ghosting) occur | • Interference occurs caused by signal reflecting from mountains or building. Try to adjust the aerial’s direction or use a better directionality antenna. |
| • Poor picture | • Choose the appropriate colour system. Refer to “COLOUR SYSTEM” on page 9.<br>• Adjust the COLOUR or BRIGHT setting. Refer to “Adjusting the picture - USER” on page 10. |
| • White and bright still image look as if it were coloured | • Inevitable phenomenon due to the nature of the picture tube. This is not a malfunction. |
| • Top of the image from software products or video tape is distorted | • This is due to the condition of the video signal whereby the image was not recorded properly. This is not a malfunction. |
| • Poor sound | • Adjust the sound frequency properly. Refer to “EQUALIZER” on page 15. |
| • Stereo or bilingual sound is unclear | • TV channel reception is poor. Change the stereo/ bilingual mode to mono sound (see page 15). |
| • Cannot operate the remote control | • The batteries may be exhausted. Replace with new batteries (see page 7).<br>• Ensure that you are operating the remote less than seven meters from the front of your TV. |
| • Cannot operate the menus | • Press TV/VIDEO button to return to TV mode and try operating the menus. |
| • Cannot operate the front control buttons | • Deactivate the CHILD LOCK function if it is turned on (see page 17). |
| • TV is turned off suddenly | • This may due to the AUTO SHUT OFF function is activated. Press the POWER button to turn on the TV. |
| • Colour patches appear at the corner of the screen | • This may due to the magnetized device such as a speaker near to your TV. Keep the device apart from your TV. Alternately, you can also use the magnetic-shielded speaker. |
| • Picture is tilted | • This may due to the earth magnetism. Refer to “PICTURE TILT” on page 11 to correct the tilt. |
| • Image takes a short period to be displayed | • Image required time to stabilize before display. This is not a malfunction. |
| • TV may emitted crackling sound | • This is due to a sudden change in temperature and it is not a malfunction. If the crackling sound is too frequent, request your service technician for inspection. |
| • Feel a slight electric shock when touching the TV screen | • This is due to the static electricity of the picture tube and it will not harm the human body. This is not a malfunction. |

# Specifications

**TV RF systems**

B, G, I, D, K, M

**Colour systems**

PAL, SECAM, NTSC 3.58 MHz, NTSC 4.43 MHz

**Receiving channels**

VHF low channel (VL), VHF high channel (VH), UHF channel (U)
Receives cable channels in mid band, super band and hyper band.

**External input / output**

| | |
|---|---|
| VIDEO-1: | S-video input*, VIDEO input, AUDIO L/R input |
| VIDEO-2/COMPONENT: | VIDEO input, AUDIO L/R input, COMPONENT VIDEO ($Y/C_B/C_R$) input (Except for AV-21CS24/AV-21CX14/AV-21YX14) |
| VIDEO-3: | VIDEO input, AUDIO L/R input (Except for AV-21CS24/AV-21CX14/AV-21YX14) |
| OUTPUT: | VIDEO output, AUDIO L/R output |
| Headphone jack: | Stereo mini jack (3.5 mm diameter) |

*Except for AV-29LS24/AV-29LX14/AV-25LS24/AV-25LX14/AV-21CS24/AV-21CX14/AV-21DX14/AV-21LX14/AV-21YX14.

****Sound-multiplex systems**

A2 or NICAM (B/G, I, D/K)

****Teletext system**

FLOF (Fastext), WST (World Standard Text)

****Language displayed by teletext**

Please see the table in the description “TEXT LANGUAGE” on page 13.

**Depends on the models, STEREO/I-II function for the Sound-multiplex systems or Teletext function may not be available. Please confirm with the chart on page 3.

***Design and specifications subject to change without notice.***

JVC
VICTOR COMPANY OF JAPAN, LIMITED

© 2004 VICTOR COMPANY OF JAPAN, LIMITED

JVC

# COLOUR TELEVISION

**EQUALIZER • CINEMA SURROUND • COMPONENT INPUT**

**AV-2934LE**
**AV-2934WE**
**AV-2953WE**
**AV-2954WE**
**AV-2983VE**
**AV-2984VE**
**AV-29LS24**
**AV-2534LE**
**AV-2553LE**
**AV-2554LE**
**AV-2583VE**
**AV-2584VE**
**AV-25LS24**
**AV-2134YE**
**AV-2134WE**
**AV-2144LE**
**AV-2153WE**
**AV-2154CE**
**AV-2154LE**
**AV-2154WE**
**AV-2174VE**
**AV-2184VE**
**AV-2183VE**

## Contents


Knowing your TV's features ..... 3
Remote control buttons and basic functions ..... 4
TV buttons and functions ..... 6
Setting up your TV ..... 7
Basic setting for picture ..... 9
Advanced setting for picture ..... 11
Original features for picture ..... 12
Basic setting for sound ..... 14
Advanced setting for sound ..... 15
Favorite channel and video setting ..... 16
Customized setting ..... 17
TV channel presetting ..... 19
Additional preparation ..... 22
Troubleshooting ..... 23
Specifications ..... Back cover


# *INSTRUCTIONS*

GGT0050-001C-H

Thank you for buying this JVC colour television.
To make sure you understand how to use your new TV, please read this manual thoroughly before you begin.

**WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.**
**CAUTION: TO ENSURE PERSONAL SAFETY, OBSERVE THE FOLLOWING RULES REGARDING THE USE OF THIS TV.**

1 Operate only from the power source indicated on the rear of the TV.
2 Avoid damaging the power cord and mains plug. When unplugging the TV, grasp the mains plug. Do not pull on the power cord.
3 Never block or cover the ventilation openings.
Never install the TV where good ventilation is unattainable.
When installing this TV, leave spaces for ventilation around the TV of more than the minimum distances as shown.




4 Do not allow objects or liquid into the cabinet openings.
5 In the event of a fault, unplug the unit and call a service technician. Do not attempt to repair it yourself or remove the rear cover.
6 The surface of the TV screen is easily damaged. Be very careful with it when handling the TV. Should the TV screen become soiled, wipe it with a soft dry cloth. Never rub it forcefully. Never use any cleaner or detergent on it.
7 If you are not going to use this TV for a long period of time, be sure to disconnect the AC plug from the AC socket.
8 The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

**WARNING: <AV-2134YE/AV-2134WE/AV-2153WE/AV-2154WE only> A REMOVABLE PLASTIC COVER IS FIXED TO THE TELEVISION'S FRONT AUDIO/VIDEO CONNECTOR. TO PREVENT THIS COVER FROM BEING ACCIDENTALLY SWALLOWED BY BABIES OR CHILDREN, REMOVE IT FROM THE TELEVISION AND STORE IT IN A SAFE PLACE. IF THE COVER IS SWALLOWED SEEK THE ADVICE OF A DOCTOR IMMEDIATELY.**

# Knowing your TV's features




**Main features**

| | |
|---|---|
| **PIP (Picture in Picture)** | You can view two different sources (e.g. TV programme and VCR sources) at the same time. |
| **TELETEXT** | You can view teletext programmes which are broadcasted by some TV channels. Teletext programme is an information in text form. |
| **A2/NICAM (STEREO / I•II)** | You can listen to the stereo sound or bilingual sound from TV programme broadcasting by A2 or NICAM Sound-multiplex system. |
| **FAVORITE CH (Channel)** | You can register up to four favorite channels for quick recall with one press. |
| **AI ECO** | TV detects the brightness of your room and automatically adjust the picture brightness to a suitable level for a better eye care. |
| **AI VOLUME** | TV adjusts the volume automatically to the same level for all TV channels to avoid sudden change of the volume when selecting different TV channel. |

**Confirm your TV's functions**

Some functions written in this instruction manual may not be available for your TV.
Please see the chart below and check the functions that are equipped for your TV's model number. The model number is indicated at the rear of your TV. When you press a button concerned to a function that is not available for your TV, it does not work and the logo "Ø" appears on the screen. For a function that is not available for your TV, it is not displayed in the menu.

| No. | Function \ Model No. | AV-2984VE / AV-2983VE | AV-2584VE / AV-2184VE / AV-2583VE | AV-2183VE | AV-2174VE | AV-2954WE / AV-2953WE | AV-2554LE / AV-2154LE / AV-2553LE / AV-2144LE / AV-25LS24 | AV-2154CE | AV-2154WE / AV-2153WE | AV-2934WE | AV-2934LE | AV-2534LE | AV-2134WE | AV-2134YE | AV-29LS24 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| ❶ | I/II (STEREO/I•II) | ○ | ○ | ○ | – | ○ | ○ | ○ | ○ | – | – | – | – | – | ○ |
| ❷ | *PICTURE BOOSTER | – | – | – | – | – | – | – | – | – | – | – | – | ○ | – |
| ❸ | *ECO | ○ | ○ | ○ | ○ | ○ | – | – | ○ | ○ | – | – | ○ | – | – |
| ❹,❻ | PIP control buttons (Green label) | ○ | ○ | ○ | ○ | – | – | – | – | – | – | – | – | – | – |
| – | PICTURE TILT | ○ | – | – | – | ○ | – | – | – | ○ | ○ | – | – | – | ○ |
| – | COMPRESS (16:9) | ○ | ○ | ○ | ○ | ○ | ○ | – | ○ | ○ | ○ | ○ | ○ | – | ○ |

# Remote control buttons and basic functions

| No. | Press | To |
|---|---|---|
| ❶ | POWER | Turn on or off the TV from standby mode. |
| ❷ | MENU/OK | Display menu and confirm selected function. |
| ❸ | ▲ / ▼ / ◄ / ► | Select and adjust menu function. |
| ❹ | CHANNEL -/+ | Select the desired channel number. |
| ❺ | VOLUME -/+ | Adjust the volume level. |
| ❻ | TV/VIDEO | Select TV or video terminal input. |
| ❼ | MUTING | Turn off the volume.<br>Press this button again to resume the volume. |
| ❽ | DISPLAY | Display the programme number or video terminal number, stereo/bilingual broadcast system and PR list (channel list) on the screen.<br>You can select the channel using the PR list.<br>**1** Press the DISPLAY button once to display the PR list.<br>**2** Press ▲ / ▼ / ◄ / ► buttons to choose a channel, then press the MENU/OK button.<br>You can confirm the favorite channels in the PR list. The channels set to favorite channels are indicated with coloured mark. |
| ❾ | 0~9, -/-- | Select the programme number. For two digits programme number, press -/--, then press the number button. |
| ❿ | RETURN + | a) Return to the frequently view channel with one touch.<br>**1** Choose the channel you want to register.<br>**2** Press and hold RETURN+ button until “RETURN PLUS PROGRAMMED!” appears.<br>To cancel, press and hold RETURN+ button until “RETURN PLUS CANCELED!” appears.<br>b) Return to the previously viewed channel, if you have not set or have cancelled the Return channel as above. |



## How to operate menus and menus locations

| To | Operation | Note |
|---|---|---|
| Display the MENU | Press the MENU/OK button ❷. | To exit the MENU, press the DISPLAY button ❸ or choose EXIT menu. |
| Display the top menu | Press ▲/▼ buttons ❸ to choose a menu title. Then press MENU/OK button ❷. | Press ▼ button ❸ to display the next page for more functions. |
| Display the 2nd menu | Press ▲/▼ buttons ❸ to choose a menu title. Then press MENU/OK button ❷. | |
| Display the 3rd menu | Press ▲/▼ buttons ❸ to choose a menu title. Then press MENU/OK button ❷. | |
| Return to the previous menu | Press the DISPLAY button ❸. | – |
| Choose the setting of a function | Press ▲/▼ buttons ❸ to choose a function. Then press the ◄/► buttons ❸ to change the setting. | Press the MENU/OK button ❷ to exit from the menu. |
| Adjust the effect level of a function | Press ▲/▼ buttons ❸ to choose a function. Then press the ◄/► buttons ❸ to adjust the effect level. | |
| Display the sub menu of a function. | Press the ▲/▼ buttons ❸ to choose a function. Then press MENU/OK buttons ❷ to display the sub menu. | – |

The following chart shows locations of functions in menus. In this manual, location of a function is described as follows:

(MENU) ➔ (Top menu) ➔ (2nd menu)

(MENU) ➔ (Top menu) ➔ (2nd menu) ➔ (3rd menu)

Note: Some functions have the 4th menus as the sub-menus.

| | Top menu | 2nd menu | Location | 3rd menu | Location |
|---|---|---|---|---|---|
| **MENU** | INPUT | EXT. INPUT | P.18 | – | – |
| | | DISPLAY | P.18 | – | – |
| | PICTURE<br>* If you want to adjust PICTURE SETTING menu, you must set PICTURE MODE menu to USER. | PICTURE MODE | P.9 | – | – |
| | | PICTURE SETTING | P.10 | – | – |
| | | WHITE BALANCE | P.10 | – | – |
| | | PICTURE FEATURES | – | VNR | P.17 |
| | | | | FAVORITE CH SETTING | P.16 |
| | | | | VIDEO SETTING | P.16 |
| | | | | COLOUR SYSTEM | P.9 |
| | | | | PICTURE BOOSTER | P.10 |
| | | | | COMPRESS (16:9) | P.11 |
| | | | | PICTURE TILT | P.11 |
| | SOUND<br>* If you want to adjust EQUALIZER menu, you must set SOUND MODE menu to USER. | STEREO/I•II | P.15 | – | – |
| | | AI VOLUME | P.15 | – | – |
| | | SOUND MODE | P.14 | – | – |
| | | EQUALIZER | P.15 | – | – |
| | | BALANCE | P.14 | – | – |
| | | SOUND TURBO | P.14 | – | – |
| | | CINEMA SURROUND | P.15 | – | – |
| | FEATURES | OFF TIMER | P.17 | – | – |
| | | CHILD LOCK | P.17 | – | – |
| | | AI ECO SENSOR | P.11 | – | – |
| | | PIP | – | PIP,SUB INPUT,SWAP | P.12 |
| | INSTALL | AUTO PROGRAM | P.19 | – | – |
| | | EDIT/MANUAL | P.19 | DELETE, MOVE, MANUAL,INSERT | P.19-P.20 |
| | | LANGUAGE | P.17 | LANGUAGE | P.17 |
| | | BLUE BACK | P.11 | – | – |
| | | AUTO SHUTOFF | P.18 | – | – |
| | | VIDEO-2 SETTING | P.18 | – | – |
| | | AI ECO DISPLAY | P.11 | – | – |
| | | TEXT LANGUAGE | P.13 | TEXT LANGUAGE | P.13 |
| | EXIT | – | – | – | – |

# TV buttons and functions

The illustrations shown below is for AV-2934WE and AV-2134YE only, which are used for explanation purpose.
Your TV may not look exactly the same as illustrated.

### Front of the TV

AV-2934WE




AV-2134YE




### Rear of the TV

AV-2934WE




AV-2134YE




| No. | Button/terminal | Description | Page |
|---|---|---|---|
| ❶ | ⏻ (main power) | Press to turn on or turn off the TV's main power. | – |
| ❷ | POWER lamp | Indicate the TV is being turned on or off.<br>No colour: TV's main power is being turned off.<br>Red : TV's main power is being turned on.<br>Note: When you turn off the power switch while TV is in standby mode, the light of power lamp will be off in 10 -15 seconds. | – |
| ❸ | ECO sensor | | – |
| ❹ | Remote control sensor | | – |
| ❺ | TV/ VIDEO | Press to select TV or video mode. | – |
| ❻ | VOLUME -/+ | Press to adjust the volume level. | – |
| ❼ | CHANNEL -/+ | Press to select the desired channel. | – |
| ❽ | MENU | Press to display the menu. | – |
| ❾ | IN (VIDEO-3) | Video and audio input jacks for VIDEO-3 mode. | 22 |
| | IN (VIDEO-2) | Video and audio input jacks for VIDEO-2 mode. | 22 |
| ❿ | 🎧 | Headphone jack. | 22 |
| ⓫ | ⊓ | Aerial socket. | 7 |
| ⓬ | OUTPUT | Video and audio output jacks. (The component video signal cannot be output.) | 22 |
| ⓭ | COMPONENT (VIDEO-2) INPUT | Video or component video, and audio input jacks for VIDEO-2 mode. You can select the input signal by setting the "VIDEO-2 SETTING" function (see page 18). | 22 |
| ⓮ | VIDEO-1 INPUT | Video or S-VIDEO, and audio input jacks for VIDEO-1 mode | 7 |
| ⓯ | TIMER lamp | Indicate the OFF TIMER function is being turned on or off.<br>No colour: The OFF TIMER function is being turned off.<br>Orange : The OFF TIMER function is being turned on. | – |

**How to operate the menus with the TV button**

| TV button | Work as same as the button on the remote control unit | Note |
|---|---|---|
| MENU | MENU/OK button | To display main menu and exit menu after finish setting. |
| CHANNEL -/+ | ▼/▲ button | To select menu function. |
| VOLUME -/+ | ◄/► button | To adjust the desired function. |

# Setting up your TV

**CAUTION**

- Turn off the equipment including the TV before connecting.

**1 Connecting the aerial cable.**




If you connect a VCR, connect the aerial output jack of your VCR and the aerial jack on the TV with the aerial cable. Then connect the output jacks of your VCR and the VIDEO-1 input jacks of the TV with the video cable (or S-VIDEO cable if available) and audio cables. For details, see the manual of your VCR.




The illustration shown is just a sample. It may not be same as your TV.

**2 Connecting the compatible main plug to the AC outlet.**



**3 Inserting batteries into the remote control.**

Insert two batteries by following the ⊕ and ⊖ polarities and inserting the ⊖ end first.

**CAUTION**:

Follow the cautions printed on the batteries.

Notes:

- Use AA/R6/UM-3 dry cell batteries.
- It the remote control does not work properly, fit new batteries. The supplied batteries are for testing, not regular use.



**4 Turn on the TV by pressing the main power button.**

JVC logo appears on the screen.

**5 Making the initial settings**

Set up your TV by pressing any button except POWER button, then operate the TV menu by following the steps as below:




- Press ▲/▼ button to select your desired language*, then press MENU/OK button.
- Press ▲/▼ button to select your desired Teletext language group. For details, see page 13.
- TV will start searching for the channels.

  To stop AUTO PROGRAM, press MENU/OK button.
- Press the red button to cancel the SETUP TOUR RESTART function.
  If you want to make initial settings again when the next time you turn on the TV, press the MENU/OK button to activate the SETUP TOUR RESTART function.
- To complete the initial setting, press the MENU/OK button. To edit the channel list, see page 19.

If the JVC logo does not appear, use LANGUAGE, TEXT LANGUAGE, and AUTO PROGRAM functions to make the initial settings. Those functions are located in the INSTALL menu.

If the JVC logo appears, although you had made the initial settings, press the TV/VIDEO button to exit from initial settings.

*For AV-25LS24/AV-29LS24, you can select your desired language as follow:
ENGLISH/РУССКИЙ/中文 /MELAYU/INDONESIA

# Basic setting for picture

## COLOUR SYSTEM

You can select the appropriate colour system when the picture is not clear or no colour appears.
Press the COLOUR SYSTEM button to select a setting.




To operate this function with a menu:

✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (COLOUR SYSTEM)

For the colour system in each country or region, see the table below:

| Area | Country or Region | System |
|---|---|---|
| Asia, Middle East | Bahrain, Kuwait, Oman, Qatar, United Arab Emirates, Yemen, etc. Indonesia, Malaysia, Singapore, Thailand, India, etc. | PAL |
| | China, Vietnam, etc. | PAL |
| | Hong Kong, etc. | PAL |
| | Islamic Republic of Iran, Lebanon, Saudi Arabia, etc. | SECAM |
| | Philippines, Taiwan, Myanmar, etc. | NTSC |
| Europe | Russia, etc. | SECAM |
| | Czech Republic, Poland, etc. | PAL |
| | Germany, Holland, Belgium, etc. | PAL |
| | UK, etc. | PAL |
| Oceania | Australia, New Zealand, etc. | PAL |
| Africa | Republic of South Africa, etc. | PAL |
| | Nigeria, etc. | PAL |
| | Egypt, Morocco, etc. | SECAM |

## PICTURE MODE

You can choose the desired picture setting with one-touch.
Press the PICTURE MODE button to select a setting.

| | |
|---|---|
| SOFT | Softens contrast and sharpness. |
| BRIGHT | Heightens contrast and sharpness. |
| STANDARD | Standard picture setting. |
| USER | You can change this picture setting as you like. Select USER and adjust following items in the PICTURE SETTING menu. (CONTRAST, BRIGHT, SHARP, COLOUR, TINT*) |

*TINT can only be adjusted in NTSC system.

To operate this function with a menu:

✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE MODE)

To return the USER setting to the default, press the blue button when the PICTURE SETTING menu appears.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

## Adjusting the picture – USER

You can adjust the desired picture setting when selecting USER in PICTURE MODE.

**1** Select the USER in PICTURE MODE under PICTURE menu.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE MODE) ➔ (USER)

**2** Select the PICTURE SETTING in PICTURE menu, then adjust the setting.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE SETTING)

| | | |
|---|---|---|
| CONTRAST | ◄ : Lower contrast | ► : Higher contrast |
| BRIGHT | ◄ : Darker | ► : Brighter |
| SHARP | ◄ : Softer | ► : Higher |
| COLOUR | ◄ : Lighter | ► : Deeper |
| TINT* | ◄ : Reddish | ► : Greenish |

*TINT can only be adjusted in NTSC system.

## PICTURE BOOSTER

You can improve picture clarity when the picture is unclear due to the low signal reception.
Press the PICTURE BOOSTER button to select the desired mode.

| | |
|---|---|
| HIGH | Perform at maximum level. |
| LOW | Perform at minimum level. |
| OFF | Cancel the function |

To operate this function with a menu:
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (PICTURE BOOSTER)

## WHITE BALANCE

You can change the white balance of the picture to better match the type of video being viewed.
Select the WHITE BALANCE in the PICTURE menu, then choose the desired setting.
✳ (MENU) ➔ (PICTURE menu) ➔ (WHITE BALANCE)

| | |
|---|---|
| NORMAL | Normal white balance. |
| COOL | Bluish white. |
| WARM | Reddish white. |

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

# Advanced setting for picture

## AI ECO SENSOR (ECO)

You can adjust TV screen contrast according to the brightness of your room.
Press the ECO button to select the desired mode.

| | |
|---|---|
| 1 | Mild contrast (recommended). |
| 2 | Even contrast. |
| OFF | Cancel the function. |

To operate this function with a menu:
✳ (MENU) ➔ (FEATURES menu) ➔ (AI ECO SENSOR)

You can display the graphic of AI ECO SENSOR on the screen. Select the AI ECO DISPLAY in the INSTALL menu, then choose ON or OFF.
✳ (MENU) ➔ (INSTALL menu) ➔ (AI ECO DISPLAY)

## Correcting the Slanting Picture (PICTURE TILT)

You can correct the picture tilt caused by the earth's magnetic force.

**1** Select the PICTURE TILT in the PICTURE FEATURES menu under PICTURE menu, then press MENU/OK button.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (PICTURE TILT)
The following display appears.




**2** Press the ▲/▼ buttons until the picture become level. Then press the MENU/OK button.

## COMPRESS (16:9)

You can convert a normal picture (4:3 aspect ratio) into a wide picture (16:9 aspect ratio).
Select the COMPRESS (16:9) in the PICTURE FEATURES menu under PICTURE menu, then choose ON or OFF.
✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (COMPRESS (16:9))

## BLUE BACK

You can set the TV to automatically change to a blue screen and mute the sound if the signal is weak or absent, or when there is no input from an antenna.

Select the BLUE BACK in the INSTALL menu, then choose ON or OFF.
✳ (MENU) ➔ (INSTALL menu) ➔ (BLUE BACK)

If you wish to continue viewing the poor picture, cancel the BLUE BACK function.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

# Original features for picture

## PIP

You can display a sub picture on the screen.
Press the PIP operation buttons to display and change the sub picture setting.

| | |
|---|---|
| PIP | Display the sub picture.<br>To cancel, press the PIP button again.<br>**Notes:**<br>• You can hear the sound from the main picture only.<br>• Main picture and sub picture will use different input sources, which are TV and VIDEO mode.<br>When the same input source are selected, the sub picture input source will change as follows:<br>Main picture / Sub picture<br>TV / VIDEO-1 → VIDEO-2 → VIDEO-3<br>VIDEO-1 / TV → VIDEO-2 → VIDEO-3<br>VIDEO-2 / TV → VIDEO-1 → VIDEO-3<br>VIDEO-3 / TV → VIDEO-1 → VIDEO-2 |
| SUB-P -/+ | Select the desired channel for sub picture. |
| (Input) | Select the input source for the sub picture. |
| (Swap) | Swap between the main picture and sub picture. |
| (Position) | Change the sub picture position.<br>Each time you press on (Position) button, the sub picture position will change as follows:<br>lower right → lower left → upper left → upper right → lower right |
| (Freeze) | Freeze the sub picture to be still. |

To operate this function with a menu:

✳ (MENU) ➔ (FEATURES menu) ➔ (PIP)

When VIDEO-2 is set to component, you can't select VIDEO-2 for sub picture.

When VIDEO-2 is set to component, if the input source of main picture is set to VIDEO-2 with component, PIP button is disabled and sub picture can't be displayed.

## TELETEXT

You can watch the Teletext broadcast channel with TEXT function.

**1** Press the TEXT button to select the desired mode as follows:

TV mode → TEXT mode → MIX mode → TV mode

**2** Press the CHANNEL -/+ buttons, number buttons or colour buttons to select other Teletext pages.

**3** Press TEXT or TV/VIDEO button to return to TV mode.

You can also operate the teletext using the following buttons:

| | |
|---|---|
| (Hold) | Hold a teletext page.<br>The (hold) are displayed at the top left of the screen.<br>To cancel, press (Hold) button again. |
| (Reveal) | Display the hidden text (e.g. answers to a quiz).<br>To cancel, press (Reveal) button again. |
| (Size) | Enlarge the teletext display. |
| (Index) | Return to the index page instantly. |
| (Cancel) | Watch TV programme while waiting for a teletext page.<br>When the teletext page is found, a page number appears at the upper left of the screen.<br>Press (Cancel) to view the teletext page. |
| (Sub-page) | Operate the (Sub-page) function.<br>Sub-page numbers are displayed at the left of the screen.<br>To cancel sub-page function, press (Sub-page) button again. |

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

**Using the List mode**

You can store and recall the favorite teletext pages in memory using the colour buttons.

**1** In TEXT mode, press the MODE button to enter the List mode.

**2** Press a colour button, then press the number buttons to enter the page number.

**3** Press and hold down the ◇ (Store) button.
The page number is blinking white to indicate that they are stored in memory.

**4** To store other favorite teletext pages, repeat Step 2 to 3.

To recall the favorite teletext page, press the MODE button, then press the colour button.
To exit the List mode, press the MODE button again.
When viewing teletext programme, menu operations are not available.
If characters on a teletext programme do not appear properly, change the TEXT LANGUAGE setting.

## TEXT LANGUAGE

You can set the Teletext language group that corresponds to the programmes.
Select TEXT LANGUAGE in the INSTALL menu, then choose the desired language group.

✳ (MENU) ➔ (INSTALL menu) ➔ (TEXT LANGUAGE)

| | |
|---|---|
| GROUP-1 | English, German, Swedish / Finnish / Danish / Hungarian, Italian, French, Spanish / Portuguese, Turkish |
| GROUP-2 | Polish, German, Estonian, Slovenian, Czech / Slovakian, Rumanian |
| GROUP-3 | Polish, German, Estonian, Lettish, Russian, Ukrainian |

Depending on the broadcast, the language set may not display properly.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

# Basic setting for sound

## SOUND SYSTEM

You can select an appropriate sound system when abnormal sound occurs even when the picture appears normally.
Press the SOUND SYSTEM button to select a setting.

→ B/G → I → D/K → M →

This function is not available in video mode.
For the sound system in each country or region, see the table below:

| Area | Country or Region | System |
|---|---|---|
| Asia, Middle East | Bahrain, Kuwait, Oman, Qatar, United Arab Emirates, Yemen, etc.<br>Indonesia, Malaysia, Singapore, Thailand, India, etc. | B/G |
| | China, Vietnam, etc. | D/K |
| | Hong Kong, etc. | I |
| | Islamic Republic of Iran, Lebanon, Saudi Arabia, etc. | B/G |
| | Philippines, Taiwan, Myanmar, etc. | M |
| Europe | Russia, etc. | D/K |
| | Czech Republic, Poland, etc. | D/K |
| | Germany, Holland, Belgium, etc. | B/G |
| | UK, etc. | I |
| Oceania | Australia, New Zealand, etc. | B/G |
| Africa | Republic of South Africa, etc. | I |
| | Nigeria, etc. | B/G |
| | Egypt, Morocco, etc. | B/G |

## SOUND MODE

You can choose the desired sound setting.
Select the SOUND MODE in SOUND menu, then choose the setting.

✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE)

| | |
|---|---|
| USER | You can change this sound setting as you like.<br>Select USER and adjust the frequencies in EQUALIZER (100, 300, 1K, 3K, 8K Hz).<br>For details, see “EQUALIZER” on page 15. |
| DYNAMIC | Emphasize on both vocal sound and music. |
| MUSIC | Emphasize on music effect. |
| NEWS | Emphasize on vocal sound. |

## BALANCE

You can adjust the volume balance between the left and right speakers.
Select the BALANCE in SOUND menu, then adjust the setting.

✳ (MENU) ➔ (SOUND menu) ➔ (BALANCE)

## SOUND TURBO

You can set the sound frequency to emphasize the low and high frequency levels.

Press the SOUND TURBO to select ON or OFF.
To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (SOUND TURBO)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

# Advanced setting for sound

## CINEMA SURROUND

You can enjoy an enhanced sound for wider audience.
Press the CINEMA SURROUND button to select a setting.

| | |
|---|---|
| OFF | Cancel the function. |
| LOW | Listen to sound with less wider audience effect. |
| HIGH | Listen to sound with more wider audience effect. |
| MONO | Listen to mono sound with stereo effect. |

To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (CINEMA SURROUND)

If slight volume distortion occurs when you select HIGH mode, change the setting to LOW mode. The CINEMA SURROUND effect will be less noticeable.

If you use CINEMA SURROUND and SOUND TURBO together, volume distortion might occurs.

## STEREO / I-II ( I/II )

You can enjoy the stereo and bilingual broadcasted programmes.
Press the I/II button to select the desired mode.

| | |
|---|---|
| | Select stereo sound. |
| | Select monaural sound. |
| I | Select bilingual I (sub I). |
| II | Select bilingual II (sub II). |
| MONO | Cancels the Multi Sound function, and the sound becomes monaural. |

This function is not available in video mode.
To operate this function with a menu:

✳ (MENU) ➔ (SOUND menu) ➔ (STEREO / I-II)

## EQUALIZER

You can adjust the sound frequencies when selecting USER mode in SOUND MODE.

**1** Select the USER in SOUND MODE under SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE) ➔ (USER)

**2** Select the EQUALIZER in SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (EQUALIZER)

The following display appears.




**3** Select and adjust the desired frequencies.

**4** Press the MENU/OK button to exit the menu.

Adjust high frequency will affect higher pitch sound and vice versa.

## AI VOLUME

You can adjust the volume of all the channels and video inputs to the same level automatically.
Select the AI VOLUME in SOUND menu, then choose ON or OFF.

✳ (MENU) ➔ (SOUND menu) ➔ (AI VOLUME)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

# Favorite channel and video setting

## To register the favorite channel

You can register and recall 4 favorite channels by using the colour buttons (red, green, yellow, blue).

**1** In TV mode, select a TV channel (PR01-99) you desired to register.

**2** Press and hold a colour button for 3 seconds or more. "FAVORITE CHANNEL ■ PROGRAMMED!" appears on the screen and current channel is registered.

**3** To register other favorite channels, repeat Step 1 to 2.

To recall the favorite channel, press the colour button.
When the TV is in Text mode, Picture in Picture or menu mode, favorite channel function is not available.

## To adjust favorite channel setting (FAVORITE CH SETTING)

You can adjust the picture and sound settings for the favorite channels.

**1** Display the PICTURE menu and select FAVORITE CH SETTING in PICTURE FEATURES menu.
✳(MENU) ➡ (PICTURE menu) ➡ (PICTURE FEATURES menu) ➡ (FAVORITE CH SETTING)

**2** Select FAVORITE CHANNEL in FAVORITE CH SETTING menu, then choose the desired favorite channel.
✳(FAVORITE CH SETTING) ➡ (FAVORITE CHANNEL)

**3** Select EFFECT, then press ◄/► button to choose ON.
To cancel the settings, choose OFF.




**4** Select the desired item that you wish to adjust.
→ CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR ←
→ SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT ←

**5** Press the MENU/OK button to exit the menu.

## To adjust the video setting (VIDEO SETTING)

You can adjust the picture and sound settings for video inputs.

**1** Display the PICTURE menu and select VIDEO SETTING in PICTURE FEATURES menu.
✳(MENU) ➡ (PICTURE menu) ➡ (PICTURE FEATURES menu) ➡ (VIDEO SETTING)

**2** Select VIDEO STATUS in VIDEO SETTING menu, then choose the desired video input.
✳(VIDEO SETTING) ➡ (VIDEO STATUS)

**3** Select EFFECT, then press ◄/► button to choose ON.
To cancel the settings, choose OFF.




**4** Select the desired item that you wish to adjust.
→ CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR ←
→ SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT ←

**5** Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

# Customized setting

## VNR

You can reduce the noise.
Select the VNR in the PICTURE FEATURES menu under PICTURE menu, then choose a setting of VNR function.

✳ (MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (VNR)

| | |
|---|---|
| OFF | VNR is turned off. |
| AUTO | Effect of VNR is automatically controlled. |
| MIN | Effect of VNR becomes minimum level. |
| MAX | Effect of VNR becomes maximum level. |

If you select MAX, the picture becomes softer even if the original picture is sharp.

## LANGUAGE

You can choose your desired on screen display language.
Select the LANGUAGE in the INSTALL menu, then choose a language.

✳ (MENU) ➔ (INSTALL menu) ➔ (LANGUAGE)

## CHILD LOCK

You can disable the front control buttons of the TV.
Select the CHILD LOCK in the FEATURES menu, then choose ON or OFF.

✳ (MENU) ➔ (FEATURES menu) ➔ (CHILD LOCK)

## OFF TIMER

You can set the TV to turn off automatically to standby mode after a set time.
Press the OFF TIMER button to select a desired period of time.




You can set the period of time to a maximum of 120 minutes in 10 minutes step.

To operate this function with a menu:

✳ (MENU) ➔ (FEATURES menu) ➔ (OFF TIMER)

When the elapsed of time left one minute, “GOOD NIGHT!” appears on the screen.
You can display the OFF TIMER menu again to confirm or change the remaining time.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

## AUTO SHUTOFF

You can set the TV to turn off automatically when no signal is received for about 15 minutes or longer after the end of a broadcast.
Select AUTO SHUTOFF in INSTALL menu, then choose ON or OFF.

✳ (MENU) ➡ (INSTALL menu) ➡ (AUTO SHUTOFF)

The AUTO SHUTOFF function does not turn off the TV's main power.
The AUTO SHUTOFF function is not available in video mode.

## VIDEO-2 SETTING

You can set the VIDEO-2 SETTING according to the video signal output from the external devices connected to the VIDEO-2 terminal.
Select the VIDEO-2 SETTING in INSTALL menu, then choose a setting.

✳ (MENU) ➡ (INSTALL menu) ➡ (VIDEO-2 SETTING)

| | |
|---|---|
| VIDEO | If a normal video signal (composite video signal) is input. |
| COMPONENT | If a component video signal ($Y/C_B/C_R$) is input. |

For connecting methods, see "Additional Preparation" on page 22.

## EXT. INPUT (TV/VIDEO)

You can select TV or video terminal input with one touch.
Press the TV/VIDEO button to select an input.
To operate this function with a menu:

✳ (MENU) ➡ (INPUT menu) ➡ (EXT. INPUT)

## DISPLAY

You can display the programme number, video terminal number and PR list on the screen.
Press the DISPLAY button to select the desired mode:

ON → OFF → PR LIST →

Choose a TV channel or a VIDEO terminal.

**1** Press the DISPLAY button to display the PR LIST.

**2** Select a programme number or video terminal by pressing the ▲/▼ button to move up/down on the programme number or press the ◄/► button to skip for each 7 programme numbers, then press MENU/OK button.




To operate this function with a menu:

✳ (MENU) ➡ (INPUT menu) ➡ (DISPLAY)

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

# TV channel presetting

## To register the TV channels automatically

You can register the TV channels into the TV's channel list automatically.

**1** Display the INSTALL menu.
✳ (MENU) ➔ (INSTALL menu)

**2** Choose AUTO PROGRAM, then press the MENU/OK button.
AUTO PROGRAM function starts, and the channels received are registered in the channel list (PR list) automatically.

**3** "SETUP TOUR RESTART?" appears.

| | |
|---|---|
| To start the SETUP TOUR | Press the MENU/OK button. Then proceed to step 5 of "Setting up your TV" on page 8. |
| To skip the SETUP TOUR | Press the Red button. |

**4** The EDIT menu appears.

| | |
|---|---|
| To edit the channel list | Proceed to the Step 3 of "To edit the channel list (PR LIST)" on page 20. |
| If a channel is not registered | Proceed to the Step 3 of "To register the TV channels manually" on this page. |
| To exit the menu | Press the MENU/OK button. |

For details of "SETUP TOUR", see page 8.

## To register the TV channels manually (MANUAL in the EDIT menu)

You can register the TV channels into the TV's channel list manually.

**1** Display the INSTALL menu.
✳ (MENU) ➔ (INSTALL menu)

**2** Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.




**3** Choose the channel which you want to register.

**4** Press the blue button to activate the MANUAL function.
The sound system of the channel appears at the right of the CH/CC number.

**5** Press the ► button to choose an appropriate sound system.
For details, see "SOUND SYSTEM" on page 14.

**6** Press the green or red button to search for the TV channel.
Searching stops when a channel is found and displayed.

**7** Repeat step 5 until your desired TV channel appears

| | |
|---|---|
| If the reception is poor | Press the blue or yellow button to fine tune the TV channel. |
| If noisy sound is heard | Press the ► button to choose an appropriate sound system. |

**8** Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

## To edit the channel list (PR LIST) (MOVE and DELETE in the EDIT menu)

You can edit the TV channel list as you like.
Note: After this operation, other channel's PR numbers will be changed.

**1** Display the INSTALL menu.
✻ (MENU) ➔ (INSTALL menu)

**2** Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.




**3** Choose the channel which you want to change PR number, or delete.

**4** Do the following action:

| | |
|---|---|
| To change the PR number (MOVE) | Press the ► button. Then move it to the PR number you want to use it for the channel. Finally press the ◄ button. |
| To delete the channel (DELETE) | Press the yellow button. |

**5** Press the MENU/OK button to exit the menu.

## To add in the new channel (INSERT in the EDIT menu)

You can add in the new channel in the TV channel list as you like. You need to find the "CH/CC" number for the TV channel. Find the "CH/CC" number corresponding to the channel number of the TV channel from the attached sheet "CH/CC number list" on page 21.

**1** Display the INSTALL menu.
✻ (MENU) ➔ (INSTALL menu)

**2** Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.

**3** Choose the PR number for which you will register a new TV channel. When you add a new TV channel of NTSC-M system, press the SOUND SYSTEM button to change the sound system to M. Then proceed to the next step.

**4** Press the green button, then press ▲/▼ buttons to choose "CC" or "CH".

**5** Press the number button to enter the remaining CH/CC number.
The TV starts to search the TV channel, and the picture of the TV channel appears. If the TV finds no TV channel, a noisy picture appears.

When a TV channel has already been registered in PR99, using the INSERT function deletes that TV channel.

✻ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

## CH/CC number

When you want to use the INSERT function on page 20, find the CH/CC number corresponding to the channel number of the TV channel from this table.

| Channel No. | Country |
|---|---|
| US | United States, Philippines, etc.. |
| CCIR | Middle East, Southeast Asia, etc.. |
| OIRT | Eastern Europe, Russia, Vietnam, etc.. |
| AUSTRALIA | Australia, etc.. |

### Channel

| CH | US | CCIR | OIRT | AUSTRALIA |
|---|---|---|---|---|
| CH 02 | US-2 | E2 | R1 | AU-0 |
| CH 03 | US-3 | E3 | | AU-1 |
| CH 04 | US-4 | E4 | R2 | AU-2 |
| CH 05 | US-5 | E5 | R6 | AU-6 |
| CH 06 | US-6 | E6 | R7 | AU-7 |
| CH 07 | US-7 | E7 | R8 | AU-8 |
| CH 08 | US-8 | E8 | R9 | AU-9 |
| CH 09 | US-9 | E9 | | |
| CH 10 | US-10 | E10 | R10 | AU-10 |
| CH 11 | US-11 | E11 | R11 | AU-11 |
| CH 12 | US-12 | E12 | R12 | |
| CH 13 | US-13 | | | |
| CH 14 | US-14, W+29 | | | |
| CH 15 | US-15, W+30 | | | |
| CH 16 | US-16, W+31 | | | |
| CH 17 | US-17, W+32 | | | |
| CH 18 | US-18, W+33 | | | |
| CH 19 | US-19, W+34 | | | |
| CH 20 | US-20, W+35 | | | |
| CH 21 | US-21, W+36 | E21 | | |
| CH 22 | US-22, W+37 | E22 | | |
| CH 23 | US-23, W+38 | E23 | | |
| CH 24 | US-24, W+39 | E24 | | |
| CH 25 | US-25, W+40 | E25 | | |
| CH 26 | US-26, W+41 | E26 | | |
| CH 27 | US-27, W+42 | E27 | | |
| CH 28 | US-28, W+43 | E28 | | |
| CH 29 | US-29, W+44 | E29 | | |
| CH 30 | US-30, W+45 | E30 | | |
| CH 31 | US-31, W+46 | E31 | | |
| CH 32 | US-32, W+47 | E32 | | |
| CH 33 | US-33, W+48 | E33 | | |
| CH 34 | US-34, W+49 | E34 | | |
| CH 35 | US-35, W+50 | E35 | | |
| CH 36 | US-36, W+51 | E36 | | |
| CH 37 | US-37, W+52 | E37 | | |
| CH 38 | US-38, W+53 | E38 | | |
| CH 39 | US-39, W+54 | E39 | | |
| CH 40 | US-40, W+55 | E40 | | |
| CH 41 | US-41, W+56 | E41 | | |
| CH 42 | US-42, W+57 | E42 | | |
| CH 43 | US-43, W+58 | E43 | | |
| CH 44 | US-44, W+59 | E44 | | |
| CH 45 | US-45, W+60 | E45 | | |
| CH 46 | US-46, W+61 | E46 | | |
| CH 47 | US-47, W+62 | E47 | | |
| CH 48 | US-48, W+63 | E48 | | |
| CH 49 | US-49, W+64 | E49 | | |
| CH 50 | US-50, W+65 | E50 | | |
| CH 51 | US-51, W+66 | E51 | | |
| CH 52 | US-52, W+67 | E52 | | |
| CH 53 | US-53, W+68 | E53 | | |
| CH 54 | US-54, W+69 | E54 | | |
| CH 55 | US-55, W+70 | E55 | | |
| CH 56 | US-56, W+71 | E56 | | |
| CH 57 | US-57, W+72 | E57 | | |
| CH 58 | US-58, W+73 | E58 | | |
| CH 59 | US-59, W+74 | E59 | | |
| CH 60 | US-60, W+75 | E60 | | |
| CH 61 | US-61, W+76 | E61 | | |
| CH 62 | US-62, W+77 | E62 | | |
| CH 63 | US-63, W+78 | E63 | | |
| CH 64 | US-64, W+79 | E64 | | |
| CH 65 | US-65, W+80 | E65 | | |
| CH 66 | US-66, W+81 | E66 | | |
| CH 67 | US-67, W+82 | E67 | | |
| CH 68 | US-68, W+83 | E68 | | |
| CH 69 | US-69, W+84 | E69 | | |

| CC | US | CCIR | OIRT | AUSTRALIA |
|---|---|---|---|---|
| CC 01 | | S-1 | | AU-5 |
| CC 02 | | S-2 | | |
| CC 03 | | S-3 | | |
| CC 04 | | S-4 | | |
| CC 05 | | S-5 | | |
| CC 06 | | S-6 | | AU-5A |
| CC 07 | | S-7 | | |
| CC 08 | | S-8 | | |
| CC 09 | | S-9 | | |
| CC 10 | | S-10 | | |
| CC 11 | | S-11 | | |
| CC 12 | | S-12 | | |
| CC 13 | | S-13 | | |
| CC 14 | A | S-14 | | |
| CC 15 | B | S-15 | | |
| CC 16 | C | S-16 | | |
| CC 17 | D | S-17 | | |
| CC 18 | E | S-18 | | |
| CC 19 | F | S-19 | | |
| CC 20 | G | S-20 | | |
| CC 21 | H | S-21 | | |
| CC 22 | I | S-22 | | |
| CC 23 | J | S-23 | | |
| CC 24 | K | S-24 | | |
| CC 25 | L | S-25 | | |
| CC 26 | M | S-26 | | |
| CC 27 | N | S-27 | | |
| CC 28 | O | S-28 | | |
| CC 29 | P | S-29 | | |
| CC 30 | Q | S-30 | | |
| CC 31 | R | S-31 | | |
| CC 32 | S | S-32 | | |
| CC 33 | T | S-33 | | |
| CC 34 | U | S-34 | | |
| CC 35 | V | S-35 | | |
| CC 36 | W | S-36 | | |
| CC 37 | W+1 | S-37 | | |
| CC 38 | W+2 | S-38 | | |
| CC 39 | W+3 | S-39 | | |
| CC 40 | W+4 | S-40 | | |
| CC 41 | W+5 | S-41 | | |
| CC 42 | W+6 | | | |
| CC 43 | W+7 | | | |
| CC 44 | W+8 | | | |
| CC 45 | W+9 | | | |
| CC 46 | W+10 | | | |
| CC 47 | W+11 | | | |
| CC 48 | W+12 | | | |
| CC 49 | W+13 | | | |
| CC 50 | W+14 | | | |
| CC 51 | W+15 | | | |
| CC 52 | W+16 | | | |
| CC 53 | W+17 | | | |
| CC 54 | W+18 | | | |
| CC 55 | W+19 | | | |
| CC 56 | W+20 | | | |
| CC 57 | W+21 | | | |
| CC 58 | W+22 | | | |
| CC 59 | W+23 | | | |
| CC 60 | W+24 | | | |
| CC 61 | W+25 | | | |
| CC 62 | W+26 | | | |
| CC 63 | W+27 | | | |
| CC 64 | W+28 | | | |
| CC 75 | | X | | |
| CC 76 | | Y | R3 | |
| CC 77 | | Z | R4 | AU-3 |
| CC 78 | | Z+1 | R5 | |
| CC 79 | | Z+2 | | AU-4 |
| CC 95 | A-5 | | | |
| CC 96 | A-4 | | | |
| CC 97 | A-3 | | | |
| CC 98 | A-2 | | | |
| CC 99 | A-1 | | | |

# Additional preparation

The illustrations shown in this section are for AV-2934WE and AV-2134YE only, which are used for explanation purpose. Your TV may not look exactly the same as illustrated.

**Before connecting**

- Read the manuals provided with the devices for the proper connection.
- Turn off all the devices including the TV.
- Note that connecting cables are not supplied.

## Connecting to front video input terminal




## Connecting to rear component/video input terminal and output terminal







When you use VIDEO-1 INPUT, you should choose to connect S-VIDEO or video input. If S-VIDEO connector and video input are connected at the same time, no picture display on the screen and the message “PLEASE DISCONNECT VIDEO-1 CABLE!” appears. In this case, you should disconnect either S-VIDEO or video input.

When connecting to COMPONENT (VIDEO-2) input, depending on the connection, choose the appropriate video input using the menu (see page 18).

# Troubleshooting

If a problem occurs when you are using the TV, check the below troubleshooting guide before calling for repair.

| | |
|---|---|
| • No picture, no sound | • Deactivate the BLUE BACK function if it is turned on.<br>• Choose the appropriate sound system. Refer to “SOUND SYSTEM” on page 14. |
| • Snowy picture | • Check the aerial cable and its connection with the TV. |
| • Stripes appear on the picture | • Interference occurs caused by other devices such as an amplifier, personal computer, or a hair drier. Move such devices away from your TV. |
| • Double-pictures (ghosting) occur | • Interference occurs caused by signal reflecting from mountains or building. Try to adjust the aerial’s direction or use a better directionality antenna. |
| • Poor picture | • Choose the appropriate colour system. Refer to “COLOUR SYSTEM” on page 9.<br>• Adjust the COLOUR or BRIGHT setting. Refer to “Adjusting the picture - USER” on page 10. |
| • White and bright still image look as if it were coloured | • Inevitable phenomenon due to the nature of the picture tube. This is not a malfunction. |
| • Top of the image from software products or video tape is distorted | • This is due to the condition of the video signal whereby the image was not recorded properly. This is not a malfunction. |
| • Poor sound | • Adjust the sound frequency properly. Refer to “EQUALIZER” on page 15. |
| • Stereo or bilingual sound is unclear | • TV channel reception is poor. Change the stereo/ bilingual mode to mono sound (see page 15). |
| • Cannot operate the remote control | • The batteries may be exhausted. Replace with new batteries (see page 7).<br>• Ensure that you are operating the remote less than seven meters from the front of your TV. |
| • Cannot operate the menus | • Press TV/VIDEO button to return to TV mode and try operating the menus. |
| • Cannot operate the front control buttons | • Deactivate the CHILD LOCK function if it is turned on (see page 17). |
| • TV is turned off suddenly | • This may due to the AUTO SHUT OFF function is activated. Press the POWER button to turn on the TV. |
| • Colour patches appear at the corner of the screen | • This may due to the magnetized device such as a speaker near to your TV. Keep the device apart from your TV. Alternately, you can also use the magnetic-shielded speaker. |
| • Picture is tilted | • This may due to the earth magnetism. Refer to “PICTURE TILT” on page 11 to correct the tilt. |
| • Image takes a short period to be displayed | • Image required time to stabilize before display. This is not a malfunction. |
| • TV may emitted crackling sound | • This is due to a sudden change in temperature and it is not a malfunction. If the crackling sound is too frequent, request your service technician for inspection. |
| • Feel a slight electric shock when touching the TV screen | • This is due to the static electricity of the picture tube and it will not harm the human body. This is not a malfunction. |

# Specifications

**TV RF systems**
B, G, I, D, K, M

**Colour systems**
PAL, SECAM, NTSC 3.58 MHz, NTSC 4.43 MHz

**Receiving channels**
VHF low channel (VL), VHF high channel (VH), UHF channel (U)
Receives cable channels in mid band, super band and hyper band.

**External input / output**

| | |
|---|---|
| VIDEO-1: | S-video input*, VIDEO input, AUDIO L/R input |
| VIDEO-2/COMPONENT: | VIDEO input, AUDIO L/R input, COMPONENT VIDEO ($Y/C_B/C_R$) input (Except for AV-2134YE/AV-2154CE.) |
| VIDEO-3: | VIDEO input, AUDIO L/R input (Except for AV-2134YE/AV-2154CE.) |
| OUTPUT: | VIDEO output, AUDIO L/R output |
| Headphone jack: | Stereo mini jack (3.5 mm diameter) |

*Except for AV-2934LE/AV-29LS24/AV-2553LE/AV-2534LE/AV-2554LE/AV-25LS24/AV-2134YE/AV-2144LE/AV-2154CE/AV-2154LE.

**** Sound-multiplex systems**
A2 or NICAM (B/G, I, D/K)

**Teletext system**
FLOF (Fastext), WST (World Standard Text)

**Language displayed by teletext**
Please see the table in the description “TEXT LANGUAGE” on page 13.

**Depends on the models, STEREO/I•II function for the Sound-multiplex systems may not be available. Please confirm with the chart on page 3.

***Design and specifications subject to change without notice.***

JVC
VICTOR COMPANY OF JAPAN, LIMITED

© 2004 VICTOR COMPANY OF JAPAN, LIMITED

**This file has been downloaded from:**

www.UsersManualGuide.com

User Manual and User Guide for many equipments like mobile phones, photo cameras, monther board, monitors, software, tv, dvd, and othes..

Manual users, user manuals, user guide manual, owners manual, instruction manual, manual owner, manual owner's, manual guide, manual operation, operating manual, user's manual, operating instructions, manual operators, manual operator, manual product, documentation manual, user maintenance, brochure, user reference, pdf manual

Downloaded from: https://www.usersmanualguide.com/